
e. Shootout

SOLDER SIDE	PIN NU	MBERS	COMPONENT SIDE
2P CONTROL DOWN	A	1	1P CONTROL DOWN
2P CONTROL UP	В	2	1P CONTROL UP
2P CONTROL LEFT	С	3	1P CONTROL LEFT
2P CONTROL RIGHT	D	4	1P CONTROL RIGHT
	E	5	
	F	- 6	
	H	7	
	J	8	SERVICE SWITCH
2P CONTROL SHOOT	K	9	1P CONTROL SHOOT
2P CONTROL JUMP	L	10	1P CONTROL JUMP
2P START SWITCH	M	11	1P START SWITCH
COIN SWITCH 2	N	12	COIN SWITCH 1
COIN COUNTER 2	P	13	COIN COUNTER 1
VIDEO BLUE	R	14	VIDEO GREEN
VIDEO SYNC	S	15	VIDEO RED
	T	16	
SPEAKER (-)	U	17	SPEAKER (+)
- 5 VOLTS	V	18	+ 12 VOLTS
+ 5 VOLTS	W	19	+ 5 VOLTS
+ 5 VOLTS	X	20	+ 5 VOLTS
GROUND	Y	21	GROUND
GROUND	Z	22	GROUND

HARNESS CONNECTOR, EMI FILTER PCB: DE-0209-0



CONTROL PANEL LAYOUT

e. Shootout (continued)

OPTION TABLES

DIPSWITCH							1	2	3	4	5	6	7	8
	1	COIN	=	1	CREDIT:	-	OFF	OFF						
COIN 1	1	COIN	=	2	CREDIT:		ON	OFF						
	1	COIN	=	3	CREDIT:		OFF	ON						
	2	COIN	=	1	CREDIT:		ON	ON					-,	
	1	COIN	=	1	CREDIT:				OFF	OFF				
COIN 2	1	COIN	=	2	CREDIT:				ON	OFF				
	1	COIN	=	3	CREDIT:				OFF	ON				
	2	COIN	=	1_	CREDIT:				ON	ON				
NOT USED					¥.		ì				OFF			
ATTRACT M	ODI	ε			NO:							OFF		
SOUND					YES:							ON		
CABINET S	TYI	LE			TABLE:								OFF	
				Ţ	JPRIGHT:	•							ON	
MODE					PLAY:	Ì								OFF
			*		FREEZE:				_	•				ON

DIPSWITCH 2				-	1	2	3	4	5	6	7	8
NUMBER		TH	IREE:	-	OFF	OFF						
OF		F	IVE:		ON	OFF						
LIVES			ONE:	,	OFF	ON						
		INFI	HTE:	1	ON	ON						
BONUS	20K &	EVERY	70K:				OFF	OFF				
LIVES	30K &	EVERY	80K:		4		ON	OFF				
	40K &	EVERY	90K:				OFF	ON	19.4			
	70K 0	NLY			18	6	ON_	ON				
DIFFICULTY		F	CASY:	į					OFF	OFF		
LEVELS		NOF	RMAL:	-		હ			ON	OFF		
		I	IARD:	1					OFF	ON		
		VERY F	IARD:			*			ON	ON		
NOT USED				-							OFF	OF